Prior art: READ and WRITE cycles

READ access cycle = T + D.




FIG. 1A PRIOR ART




FIG. 1B PRIOR ART

READ access cycle = T + T + D:




FIG. 2A




FIG. 2B

Invalid READ, termination during "dataout"





FIG. 3A

Invalid READ, termination during "access"



Invalid READ, termination during "refresh"




FIG. 3C

READ access following a WRITE:




FIG. 4A

Low frequency READ, refresh operation can be inserted between "access" and "dataout"







FIG. 4B







Refresh






FIG. 7B



Timing diagram for a normal read access



Stoel Rives LLP 900 SW Fifth Ave. Suite 2600 Portland, OR 97204 (503) 224-3380

Timing diagram for an invalid read operation terminated within T of starting




FIG. 10

Timing diagram for an invalid read operation terminated within 2*T of starting




FIG. 11

Timing diagram of a write cycle




FIG. 12

Stoel Rives LLP 900 SW Fifth Ave. Suite 2600 Portland, OR 97204 (503) 224-3380

Timing diagram of a write cycle immediately followed by a read




FIG. 13